




-  Insulation / HV bushing
-  primary coils
-  secondary coils
-  main body

Note:

This diagram represents the internal assembly and cross-sectional layout of a three-phase distribution transformer for wind farm applications.

All dimensions are in centimeters (cm).

The drawing illustrates the arrangement of HV/LV bushings, core-coil assembly, and thermal management (radiator fins)

Transformer Cross section



Wind Xpertz	ME-109 Engineering Drawing		Page -/-	
	Wind farm			
	Drawn			
	By:			
	supervised			
	By:			