





Note:
These diagrams
represents yaw system
that turn the direction
of the nacelle.
And
The air speed sensor
or the anemometer
used in windmills

All dimensions are in
centimeters (cm).

Yaw system

Annemometer

	
Windxpertz	
ME-109 Engineering Drawing	
Wind farm	
Drawn By: supervised By:	